

TEST REPORT

Applicant: SAVEWO LIMITED
1/F
266-270 TEXACO RD
TSUEN WAN NT
HK

Number: HKGH0284884303 S4

Date: Mar 28, 2022

Attn: ZEN DING

This is to supersede Report No. HKGH0284884303 S3 dated Mar 28, 2022 due to information update

Sample and Information provided by customer :
Item Name : **FreshQ Portable Electrolytic Sterilizer - Disinfectant**
Date sample received : Mar 14, 2022
Testing period : Mar 16, 2022 to Mar 25, 2022

Conclusion:
The submitted sample was tested under the following requirements requested by the applicant, subject to the information stated in the remark and attached page(s) for details :

Requirement	Result
(1) Hypochlorite content	See details enclosed

Decision Rule(s):
When a statement of conformity to a specification or standard is provided on test report, the decision rule shall be applied. For details, please refer to Intertek's "Decision Rule Document" and is available on Intertek's website. <https://intertekhk.grd.by/decision-rule-doc..>
If decision rule already in hered in the requested specification or standard, Intertek's "Decision Rule Document" is not applicable and indication of "∞" was shown as above table.

For and on behalf of :
Intertek Testing Services HK Ltd.



Cindy I.K. Chan
Vice President



TEST REPORT

Number : HKGH0284884303 S4

(1) Hypochlorite content

Test Method: Iodometric Titration with Reference to ASTM D2022-89 (2016) Standard Test Methods of Sampling and Chemical Analysis of Chlorine-containing Bleaches

Tested Component:	Result: (as hypochlorous acid)
1	<20 ppm
2	21 ppm
3	200 ppm
4	327 ppm

Remark :
ppm = parts per million or milligrams per kilogram

Component List :

- 1: Savewo tap water activates for 3 mins (mode 1).
- 2: Savewo tap water activates for 5 mins (mode 2).
- 3: Savewo 3g salt/ 300 ml water activates for 3 mins (mode 1) (prepared by lab).
- 4: Savewo 3g salt/ 300 ml water activates for 5 mins (mode 2) (prepared by lab).

Date sample received : Mar 14, 2022
Testing period : Mar 16, 2022 to Mar 25, 2022

End of report

This report is for the exclusive use of Intertek's Client and is provided pursuant to the agreement between Intertek and its Client. Intertek's responsibility and liability are limited to and subject to our standard Terms and Conditions which can be obtained at our website: <http://www.intertek.com/terms/>. Intertek assumes no liability to any party, other than to the Client in accordance with the agreement, for any loss, expense or damage occasioned by the use of this report. Intertek is responsible for all the information provided in the reports, except when information is provided by the Client or when the Client requires the item to be tested acknowledging a deviation from specified conditions that can affect the validity of results.

The observations and test results in this report are relevant to the sample(s) tested and submitted by client. The report is not intended to be a recommendation for any particular course of action, you are responsible for acting as you see fit on the basis of the report results. This report does not discharge or release you from your legal obligations and duties to any other person. Only the Client is authorized to permit copying or distribution of this report and the report shall not be reproduced except in full. Any use of the Intertek name or one of its marks for the sale or advertisement of the tested material, product or service must first be approved in writing by Intertek. This report by itself does not imply that the material, product, or service is or has ever been under an Intertek certification program.



To: SAVEWO LIMITED
Attention: ZEN DING

Ref: FC-2022-1852
Date: Apr 07, 2022

Re : Report Revision Notification

Intertek Testing Services Report Number HKGH0284884303 S3 Dated Mar 28, 2022

Please be informed that all the content recorded in the above captioned report will be void. This captioned report is now superseded by a revised Intertek Testing Services report, HKGH0284884303 S4.

Thank you for your attention.

For and on behalf of :
Intertek Testing Services HK Ltd.



Cindy I.K. Chan
Vice President

