

# TEST REPORT

Applicant: SAVEWO LIMITED  
1/F  
266-270 TEXACO RD  
TSUEN WAN NT  
HK  
  
Attn: ZEN DING

Number: HKGH02870816  
  
Date: Jul 14, 2022

Sample and Information provided by customer :  
Item Name : **FreshQ Portable Electrolytic Sterilizer – Disinfectant  
3g Salt/300ml water, Mode 2 (5 mins)**

\*\*\*\*\*

For and on behalf of :  
Intertek Testing Services HK Ltd.



Cindy I.K. Chan  
Vice President



# TEST REPORT

Number : HKGH02870816

**Conclusion:**

The submitted sample was tested under the following requirements requested by the applicant, subject to the information stated in the remark and attached page(s) for details :

<u>Requirement</u>	<u>Result</u>
(1) BS EN 14476:2019 (with modification) *****	See details enclosed

**Decision Rule(s):**

When a statement of conformity to a specification or standard is provided on test report, the decision rule shall be applied. For details, please refer to Intertek's "Decision Rule Document" and is available on Intertek's website. <https://intertekhk.grd.by/decision-rule-doc..>  
If decision rule already inhered in the requested specification or standard, Intertek's "Decision Rule Document" is not applicable and indication of "∞" was shown as above table.  
\*\*\*\*\*



## TEST REPORT

Number : HKGH02870816

(1) Quantitative suspension test for evaluation of virucidal activity of chemical disinfectants and antiseptics

Reference standard :	BS EN 14476:2019 (with modification)
Dilution recommended for use:	No dilution
Product test concentration:	80% (v/v)
Active ingredient in product:	Hypochlorite
Appearance:	Colorless liquid
Contact time:	10 seconds
Test temperature:	23°C
Interfering substance:	0.3 g/L bovine albumin (clean condition)
Incubation:	37°C/5% CO <sub>2</sub>
Viral culture:	SARS-CoV-2 (hCoV-19/Czech Republic/NRL_6632_2/2020)
Concentration of inoculum:	10 <sup>6</sup> PFU/mL



Page 3 of 4



# TEST REPORT

Number : HKGH02870816

Result :

Test Organism	Control Titre PFU/mL	Sample Titre PFU/mL	Log <sub>10</sub> Reduction Criteria: R ≥ 4.0	% Reduction Criteria: R ≥ 99.99	Assessment
SARS-CoV-2 (hCoV-19/Czech Republic/NRL_6632_2/ 2020)	283,589	0	>5.0	>99.999	Satisfactory

Criteria: According to BS EN 14476, in order to satisfy the requirement of virucidal efficacy of chemical disinfectants and antiseptics, the product shall demonstrate at least 4.0 log<sub>10</sub> reduction of the specified test organism.

Date sample received : Apr 29, 2022  
Testing period : Apr 29, 2022 to Jul 07, 2022

\*\*\*\*\*

End of report

*This report is for the exclusive use of Intertek's Client and is provided pursuant to the agreement between Intertek and its Client. Intertek's responsibility and liability are limited to and subject to our standard Terms and Conditions which can be obtained at our website: <http://www.intertek.com/terms/>. Intertek assumes no liability to any party, other than to the Client in accordance with the agreement, for any loss, expense or damage occasioned by the use of this report. Intertek is responsible for all the information provided in the reports, except when information is provided by the Client or when the Client requires the item to be tested acknowledging a deviation from specified conditions that can affect the validity of results.*

*The observations and test results in this report are relevant to the sample(s) tested and submitted by client. The report is not intended to be a recommendation for any particular course of action, you are responsible for acting as you see fit on the basis of the report results. This report does not discharge or release you from your legal obligations and duties to any other person. Only the Client is authorized to permit copying or distribution of this report and the report shall not be reproduced except in full. Any use of the Intertek name or one of its marks for the sale or advertisement of the tested material, product or service must first be approved in writing by Intertek. This report by itself does not imply that the material, product, or service is or has ever been under an Intertek certification program.*

